


Uniden


UPGRADING MONITOR FIRMWARE

1. Download and unzip attachment. Copy the UBR243.bin file into the root folder of the SD card.


[Download](#) 



2. Power up the monitor, insert the SD card with firmware. Press the SD card button on the monitor to locate the Play File List.




3. Press and hold ZOOM and TALK buttons at the same time until UBR243.bin appears.



4. Select UBR243.bin and press the joystick to start upgrade. It will take around 5 minutes.



5. Reboot the monitor after upgrading is done.



6. In Live View Mode, press Vol+>Vol->Vol+>Vol->Joy Stick to double check the firmware version. Press back button to exit the firmware version view.

