


# UPGRADING GUARDIAN APP CAM 24/25/26 FIRMWARE

## Overview

To upgrade the App Cam 24/25/26 firmware, you will need to download the upgrade file from the Uniden website ([www.uniden.com.au](http://www.uniden.com.au)) to your computer.

## Instructions:

1. Disconnect the power from your App Cam.
2. Download the firmware to your computer. 
3. Unzip the file to a folder on your computer.
4. Insert the microSD card into your computer (an adapter may be necessary).
5. Copy the firmware to the root directory of your microSD card.
7. Eject the microSD card and place into your AppCam.
8. Connect the power to your App Cam.
9. Power up the camera and wait around 3 minutes until camera green LED starts flashing slowly. Do not attempt to power off the camera at any stage.
10. The App Cam will install the firmware.
11. App Cam will reboot after firmware upgrade completed.
12. Remove the registered DID on the mobile application if it was set up previously.
13. User will need to reset the system to connect camera to Wi-Fi and Internet.
14. When the setup is finish, go to live view to make sure the connection is good.
15. You should able to receive push notification when the camera detects motion.

Any further settings, please refer to the full Owner's Manual on Uniden website.

[Download](#)

