

# Uniden®

## UPP1000

Portable Power Bank &  
Jump Start Kit

---

For more exciting new products please visit our website:  
Australia: [www.uniden.com.au](http://www.uniden.com.au)


---

# Uniden®

© 2019 Uniden Australia Pty Limited.  
Printed in PRC v1.0

# OWNER'S MANUAL

## UPP1000 OVERVIEW



## FEATURES

- 10000mAh Capacity
- Universal 12V Jump Start clamps
- Supports Engines  
< 7.0L Petrol  
< 5.0L Diesel
- LED Flashlight
- USB Output:  
5V/3A, 9V/2A, 12V/1.5A
- USB Type-C Input & Output:  
5V/3A, 9V/2A, 12V/1.5A
- Resting Discharge  
– 20% Loss/Year
- Carry Pouch

## WHAT'S INCLUDED

- UPP1000 Jump Starter Unit
- Smart Jumper Cable Adaptor
- USB Cables (Micro, Mini & Type-C)
- Cigarette Lighter Charger (vehicle adaptor)
- Wall Charger
- Carry Pouch

## USING THE UPP1000 POWER BANK

### CHARGING THE UNIT

1. Connect the unit and the power source via the USB C cable or Micro USB cable.
2. While charging the unit, the battery level indicator light will flash. The battery level indicator will stay solid with when charging is complete.
3. Disconnect the UPP1000 when fully charged.

***To preserve battery life, fully charge the Power Bank every three months.***

### CHARGING USB DEVICE (TABLET, CELL PHONE, ETC.)

1. Connect the unit and smart phones or other electronic devices with the included USB cable.
2. The UPP1000 begins to charge your device provided the unit has enough power.
3. Unplug the USB cable when electronic devices are fully charged.

### CHECK BATTERY CAPACITY

Press the **POWER** button without any devices connected to the charger. The number of bars in the battery icon indicate the power in the battery, 25%, 50%, 75% and 100%.

### TURN ON LED FLASHLIGHT

Press the **POWER** button to turn on the unit. Then press and hold the **POWER** button to turn on the LED flashlight. Press the **POWER** button again to cycle through the 3 modes: Steady, SOS and Fast Strobe.

## JUMP START A VEHICLE

1. Insert the plug of the smart battery clamp completely into the jump starter.
2. Connect the red clamp to the positive terminal (+) of the car battery and connect the black clamp to the negative terminal (-) of the car battery.
3. Start your car.

If you failed to start your car, you need to disconnect the battery clamp from the vehicle and the jump starter. Wait for at least 30 seconds, then try again.

If you failed to start your car after 3 attempts, you can press and hold the force start button for 3 seconds until the indicator light of the smart clamp turns solid green, you need to start the vehicle within 30 seconds.

4. Once your car is started, remove the battery clamp from the car battery and the jump starter within 30 seconds.

Indicator Light	Smart Battery Clamp Status
Red and green lights flashing alternately	In standby mode, ready to use after you correctly connected polarity of clamps and battery terminal
Solid green light	Force start function is ready to use.
Solid red light	Battery clamp is reversely connected, or short-circuited.
Red light flashing	The over-temperature protection is triggered because the temperature of the clamp exceeds 60°C. The output would be automatically shut off. The red indicator light would flash. When the temperature drop lower than 55°C, the red and green indicator light would flash alternately.
Green light flashing	The voltage of the unit is too low. You need to charge the product in time.

## MAINTENANCE

Check the battery level of the unit at least once every three months and charge the unit regularly. Please handle the product with care and store the unit in a shaded, well-ventilated area. Avoid dropping or striking the product heavily and repeatedly.

Do not use the unit to start a bulging car battery, disassemble or modify and use detergents to clean the unit. DO NOT place the products in a high-temperature environment for long.

## BATTERY DISPOSAL

The battery is self-contained and not consumer replaceable. The battery must be disposed properly when it no longer holds a charge. Proper charging practices will prolong the shelf life of the unit.

## SPECIFICATIONS

<b>UPP1000</b>	
Capacity	10000mAh/37WH
Start Current	500A (last for 1s)
Peak Current	1000A (last for 0.2s)
Micro USB Input	5V/2.4A Max
USB Output 1	5V/3A, 9V/2A, 12V/1.5A Max
USB Output 2	5V/3A, 9V/2A, 12V/1.5A Max
USB Type-C Input & Output	5V/3A, 9V/2A, 12V/1.5A Max
USB Type-C Power	18W Max
Short Circuit Protection	Yes
Over-discharge Protection	Yes
Reverse Polarity Protection	Yes
Reverse Charging Protection	Yes
Cycle life	1,000 times
Operating Temperature	- 20° ~ + 60° C

## **ONE-YEAR LIMITED WARRANTY**

### **UPP1000**

**IMPORTANT Satisfactory evidence of the original purchase is required for warranty service**

Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

### **Warrantor**

The warrantor is Uniden Australia Pty Limited ABN 58 001 865 498.

### **Terms of Warranty**

Uniden Aust warrants to the original retail purchaser only that the UPP1000 (“the Product”), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

### **Warranty Period**

This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale.

If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- (A) Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner’s Manual;
- (B) Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust;
- (C) Improperly installed contrary to instructions contained in the relevant Owner’s Manual
- (D) Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- (E) Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

### **Parts Covered**

This warranty covers the Product and included accessories.

### **User-generated Data**

This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

### **Statement of Remedy**

If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product’s failure to comply with the warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

### **Procedure for Obtaining Warranty Service**

Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden. Please refer to the Uniden website for address details. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

### **UNIDEN AUSTRALIA PTY LTD**

Phone number: 1300 366 895

Email: [custservice@uniden.com.au](mailto:custservice@uniden.com.au)