

# Uniden®

## **XDECT SSE07** Accessory Handset

---

*For more exciting new products please visit our website:  
Australia: [www.uniden.com.au](http://www.uniden.com.au)*

---

# OWNER'S MANUAL

## IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- **This unit is NOT waterproof.** DO NOT expose this unit to moisture.
- DO NOT expose this unit to rain.
- Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.

---

### **SAVE THESE INSTRUCTIONS!**

---

#### ***Important Notice***


Under power failure conditions this appliance may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use.

#### **General Notices for New Zealand Model:**

- The grant of a NZ Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.
- The maximum volume setting of this telephone exceeds the Telecom specified volume requirement. Telecom takes no responsibility for the high volume available on this telephone, who believe this telephone is too loud should contact the manufacturer at the website indicated on owner's manual warranty page.
- For telephone networks other than Telecom there may be a charge incurred for local calls if the Insert 0 feature is on. Turn Insert 0 off.
- This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

## SSE07

### What's in the Box?




If any of the item is missing or damaged, contact your place of purchase immediately. ***Never use damaged products!***

Need help? Get answers at our website:  
***www.uniden.com.au*** for Australian model

## INSTALLING YOUR HANDSET

### Charge the Battery

1. Unpack the handset, battery pack, and battery cover. If you need to remove the cover, press in on the notch and slide the cover down and off.
2. Line up the battery connector with the jack inside the handset; the connector only fits one way.
3. Push the connector in until it clicks into place; tug gently on the wires to make sure the battery is securely connected.
4. Replace the battery cover and slide it into place.
5. Use the AC adaptor to connect the power jack on the charger to a regular indoor (240V AC) power outlet.
6. Place the handset on the charger with the display facing forward. If the display doesn't light up, reseal the handset or connect the charger to a different outlet.



 **Charge the handset completely (about 15 hours) before using it.**

## REGISTERING TO A BASE

The accessory handset won't work until you register it to a compatible Uniden cordless phone!

### Compatible Bases

This handset is designed for use with Uniden's SSE45 and SSE47 bases.

### Registration Methods

Does the handset fit in the base cradle?				
Yes	Place the handset in the base. The display should say <i>Registering</i> .			
No	<b>Does the base have an LCD display?</b>			
	<table border="1"><tbody><tr><td>Yes</td><td>On the base, press <b>MENU/OK</b> to open the menu and then scroll to <i>Register Accy</i>. Press <b>MENU/OK</b>. On the handset, press and hold <b>#DND</b> until the handset display shows <i>Registering</i> (about 2 seconds).</td></tr><tr><td>No</td><td>On the base, press and hold <b>FIND HS</b> when the phone is in standby (about 5 seconds). On the handset, press and hold <b>#DND</b> until the handset display shows <i>Registering</i> (about 2 seconds).</td></tr></tbody></table>	Yes	On the base, press <b>MENU/OK</b> to open the menu and then scroll to <i>Register Accy</i> . Press <b>MENU/OK</b> . On the handset, press and hold <b>#DND</b> until the handset display shows <i>Registering</i> (about 2 seconds).	No
Yes	On the base, press <b>MENU/OK</b> to open the menu and then scroll to <i>Register Accy</i> . Press <b>MENU/OK</b> . On the handset, press and hold <b>#DND</b> until the handset display shows <i>Registering</i> (about 2 seconds).			
No	On the base, press and hold <b>FIND HS</b> when the phone is in standby (about 5 seconds). On the handset, press and hold <b>#DND</b> until the handset display shows <i>Registering</i> (about 2 seconds).			

 After about 30 seconds, the handset display should say, *Registration Complete*.

### Test the Connection

Pick up the handset and press **TALK/FLASH**. Make sure you get a dial tone. (Press **END/CLEAR** to hang up.)

If..	Try..
you don't hear a dial tone the display shows <i>Registration Failed</i>	charging the handset fully, and then attempt testing the connection again.

## IMPORTANT INFORMATION

1. All features and operation for the handset are described in the owner's manual for the base.
2. Owner's Manual for all Uniden phones are available on our website for free downloading.

### AC Adaptor

Parts Number	Input Voltage	Output Voltage
AAD-600S(R)	100-240V AC, 50/60Hz	9V DC @ 210mA

### Battery Information

Type	Capacity	Talk time	Standby Time
BT-694 or BT-694s BT- 694n	650mAh or 500mAh or 400mAh	about 10 hours	about 7 days

- Use only the supplied AC adaptors.
- Use the proper adaptor for the base and any charger.
- Do not place the unit in direct sunlight or subject it to high temperatures.
- Replace the battery when the talk or standby time becomes noticeably reduced. For replacements, visit the online shop on our website (see the front cover).
- When the battery gets low, the handset beeps and shows a low battery alert; put the handset in the cradle for recharging.

# ONE-YEAR LIMITED WARRANTY

## XDECT SSE07

### **Important:**

Satisfactory evidence of the original purchase is required for warranty service. Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

### **Warrantor:**

The warrantor is Uniden Australia Pty Limited ABN 58 001 865 498 ("Uniden Aust").

**Terms of Warranty:** Uniden Aust warrants to the original retail purchaser only that the SSE07 ("the Product"), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

**Warranty Period:** This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale. If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- A. Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner's Manual;
- B. Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust;
- C. Improperly installed contrary to instructions contained in the relevant Owner's Manual
- D. Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- E. Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

**Parts Covered:** This warranty covers the Product and included accessories.

**User-generated Data:** This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

**Statement of Remedy:** If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

**Procedure for Obtaining Warranty Service:** Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden. Please refer to the Uniden website for address details. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

**UNIDEN AUSTRALIA PTY LTD**

Phone number: 1300 366 895

Email: [custservice@uniden.com.au](mailto:custservice@uniden.com.au)

**Uniden**<sup>®</sup>

© 2017 Uniden Australia Pty Ltd

Printed in Vietnam U01UU915ZZZ(0)