## Uniden

## **ADDING UNIDEN SOLO+ CAMERAS TO AMAZON ALEXA**

## Overview

To use your Uniden Solo+ cameras with Amazon Alexa, you need to have the following devices and apps set up: Uniden Solo+ camera and an Echo device with screen. You will also need the Amazon Alexa app on your mobile device.

If the current camera firmware is not compatible with Amazon Alexa, please contact us at securitysupport@ uniden.com.au for more information.

Before you start, ensure your Amazon Alexa and Echo device are setup and working.

## Linking Uniden Solo+ to Amazon Alexa

Step 1. Launch the Uniden Solo App and log in your cloud account, and then you will find the Smart Home option. If you can't find the Smart Home option, please contact securitysupport@uniden.com.au for more information.



Step 2. Enable the device you want to add to Amazon Alexa in the Smart Home page.



Step 3. Launch the Amazon Alexa app, sign in your Amazon Alexa account.

Step 4. From the Amazon Alexa app,tap the Menu icon in the top left corner. Select the Skills & Games option from the menu.



Step 5. Tap and search for "Uniden Solo". "Uniden Solo" skill will appear in the results. .



Step 6. Select the skill and tap ENABLE TO USE on the Uniden Solo skill page.

	solo ح			
Uniden Australia Rated: Guidance Suggested	P			
ENABLE TO USE				
Account linkin	ng required			
Enable the Uniden Solo Skill in your Alexa App, and you can check-in on your property by simply saying "Alexa, show the front door." Please note that you are only able to view video See More				
Start By Saying	English (AU) 🗸			
'Alexa, show the front door camera.'				
Alexa show the l	iving room Play Devices			

Step 7. You will need to link your Uniden Solo account. Enter the email and password registered with your cloud account, then tap Login.

×	My Account - Uniden my.uniden.com.au	:
	LOG III sign up	
	Email	
	Password ~	
	Log in	
	Lost your password?	

Step 8. Once your account is linked, this page will appear. Close this page by tapping the "X" at the top left corner.



Step 9. You will now be prompted to discover your cameras. Tap DISCOVER DEVICES. Alexa will search for the cameras registered with your Uniden Solo account.

Discover Devices		
Smart Home devices must be discovered before they can be used with Alexa.		
CANCEL	DISCOVER DEVICES	

Step 10. When the discovery process is completed, tap CHOOSE DEVICE and finish the setup. Alexa is now ready to interact with your Uniden Solo+ cameras.



Step 11. To test your camera, and say "Alexa, can you show [name of the camera]" to your Echo device.